



HOW TO INSTALL SCAN~LINK RFID SAFETY SYSTEM® INTO HARD HAT INTERIOR

STEP 1: Remove hard hat suspension and clean any dirt, grease and grime from the *interior* surface of the hard hat.

STEP 2: Apply all ten (10) SCAN~LINK Armour® Tags one at a time to the *interior* of the hard hat at the locations shown in the diagram below. Ensure that the tags **A, B, C** and **D** are placed **3" (8cm)** above the headband.

HOW TO INSTALL SCAN~LINK RFID SAFETY SYSTEM® INTO HARD HAT INTERIOR

STEP 1

Remove hard hat suspension and clean any dirt, grease and grime from the **interior** of the hard hat.

STEP 2

Apply all ten (10) SCAN~LINK Armour® Tags one at a time to the interior of the hard hat at the locations shown in the diagram below – ensuring that tags **A, B, C** and **D** are placed **3" (8 cm)** above the rim of the hard hat.


STEP 3

Confirm tags are secured as shown in STEP 2, and re-install hard hat suspension.

Your hard hat is now:

SCAN~LINK Armour® Ready!

ALL TEN (10) TAGS GO INSIDE THE HARD HAT



DO NOT OVERLAP TAGS

ALL SCAN~LINK SAFETY PRODUCTS ARE DESIGNED AS TOOLS TO ASSIST OPERATORS ONLY AND DO NOT TAKE AWAY ANY RESPONSIBILITY OF THE OPERATOR WHEN BACKING UP. SCAN~LINK WILL NOT BE HELD LIABLE FOR ANY DAMAGE, INJURY OR LOSS ASSOCIATED WITH ITS SAFETY PRODUCTS. THE SCAN~LINK SYSTEM DOES NOT REPLACE ANY SAFETY PROCEDURE OR RESPONSIBILITY IN PLACE.

TAGS GO INSIDE HARD HAT

STEP 3: Confirm the tags are secured as shown in STEP 2, and re-install the hard hat suspension. Your hard hat is now **SCAN~LINK Armour® Ready!**