

Rapid Pair

PN# SLRP-SN220



OUTLINE

The RapidPair™ tool allows the user to configure, maintain, and monitor the SCAN-LINK Armour System™. The RapidPair™ software provides a visual means to quickly pair devices together by forming a connection between devices that are required to communicate with each other. Devices that can be paired together are found by RapidPair™ and displayed on the screen. The RapidPair™ software allows for the pairing and configuration of both the SCAN~LINK Antenna and Display Units, as well as for configuration of the SCAN~LINK Tag Health Tester.

RapidPair™ is used to retrieve important and valuable data collected from the antenna unit which is installed on the vehicle. The type of data collected from a SCAN-LINK equipped vehicle is :

- number of detections
- time and date of detections
- apparel type and tag type
- whether the safety vest was facing forward or backward

SPECIFICATIONS

System Requirements

Operating system		
Windows 10 (32 and 64-bit)	RAM	1GB (min)
Windows 8 (32 and 64-bit)	HDD	50MB free (min)
Windows 7 (32 and 64-bit)	Ports	1x USB 2.0
Windows Vista (32 and 64-bit)		
Windows XP		
Electrical (RPD-SN220 USB Dongle)		
System Voltage 5VDC (USB bus powered)	Current	100mA max.
Wireless Link 2405-2475MHz Unlicensed ISM Band, 0.098W EIRP		
Contains	IC ID: 9084A-SM220 Under Synapse Wireless Inc.	
	FCC ID: U90-SM220 Under Synapse Wireless Inc.	
	IFT ID: 201801A01279 Under Synapse Wireless Inc.	

For more information, please contact us via one of the methods below:

Toll free	+1-866-554-5582
Phone	+1-905-304-6100
Email	info@scan-link.com
Website	www.scan-link.com